




Operation Manual

- Thank you for purchasing this great product.
- Please take a few moments to read through the manual to ensure proper operation.
- Please keep the instruction manual for future reference.

ITEM NO.: G003

the switch and adapter port can be found on the rear of the unit.



Put the additional case onto the watch holder for larger sized wristwatch. The additional case is including in the package.

Item Specification

Power	Input:AC/100-240V,50-60Hz ; Output:DC/4V 500mA		
Feature	1. wind clockwise or anticlockwise by operating the switch 2. Count down Function:Auto rotate 1 hour & rest for 3 hours 3. TPD:2160 turn per day. 4. Temperature: Operate between 5°C to 40°C.		
Size	128x140x156mm (L*W*H)		
Weight	About 400g (without adapter)	Accessory	AC Adapter

Note:

- * Please use the AC adapter Input:AC/100-240V,50-60Hz Output:DC/4V 500mA supplied with the unit.
- * Remove the adapter when the winder is not in use.
- * Always turn off the power when inserting or removing watches.
- * Don't shake or rotate when winder is stationary.



Operation:

1. Insert the adapter into the adapter port and plug it into the electrical outlet.
2. Open the front cover, then use your index finger and thumb to hold the watch winder from the two sides of the holder which marked with two arrows. With some force, pull out the watch holder.
3. Place the watch around the holder by pushing in the spring in the back of the holder, then placing your watch around the holder, then let go of the spring.
4. Once the watch is on the holder, place the holder back into the winder. Push until you hear a click signifying that it is securely in the winder.
5. Close the cover
6. Slide the switch to have the different rotating directions.
 - * Slide the switch up, the winder will turn clockwise.
 - * Slide the switch down, the winder will turn anticlockwise.
 - * Slide the switch at the center position, to turn the unit off.



Attention:

- * If you do not use this product for a long time, please switch off the unit.
- * Make sure to turn the unit off completely before attempting to pull out the watch holder.
- * For warranty information please contact the retailer you purchased from.